

Quick Start Guide

Introduction to the Team Cuisine Cooking Machine App

The Smart Cooking Machine can be paired with your mobile device and controlled through our Companion App, enabling you to cook, schedule, adjust and monitor the progress of your meals on the go, browse recipes, save to favorites and filter them based on the ingredients.


Pairing the device with your Smart Cooking Machine




Turn on the Smart Cooking Machine.




Press and hold the **MODE** button for 5 seconds until the status LED blinks.



The Smart Cooking Machine is now ready for pairing.



When the app finds the Smart Cooking Machine, select **Pair Now** on the app. (Select **Search Again** if the Smart Cooking Machine is not found.)



It will take a few minutes to connect the device and your Smart Cooking Machine.




After successfully pairing the devices, tap Next to enter the app's control page.

Quitting Pairing Mode

Press and hold the **MODE** button for 5 seconds until the status LED blinks.

NOTE: If the mobile device does not connect to the Smart Cooking Machine within 2 minutes, the Bluetooth pairing mode will time out.



www.team-cuisine.com



Apple, the Apple logo and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries and regions. App Store is a service mark of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. All other trademarks are properties of their respective owners.

Guide de Démarrage Rapide

Guide d'utilisation de l'application accompagnant Team Cuisine Cooking Machine


Vous pouvez connecter votre Machine à Cuisiner Intelligente à votre appareil mobile et la commander via notre application compagnon. Cette application vous permet de programmer les différentes fonctions de cuisson et de suivre, à tout moment, les fonctions activées. Vous pouvez également utiliser cette application pour parcourir différentes recettes, les enregistrer dans vos favoris et les filtrer en fonction des ingrédients dont vous disposez.


Jumelage de votre appareil mobile avec votre machine à cuisiner



Mettez votre machine à cuisiner intelligente sous tension.



Appuyez sur la touche **MODE**  et maintenez-la enfoncée pendant 5 secondes jusqu'à ce que le voyant d'état se mette à clignoter.



Votre machine à cuisiner est alors prête à être jumelée.



Une fois que l'application aura détecté votre machine à cuisiner, appuyez sur **Jumeler maintenant** dans l'application. (Appuyez sur **Rechercher à nouveau** si votre machine à cuisiner n'est détectée).



Le jumelage de l'appareil et de la machine à cuisiner peut prendre quelques minutes.



Une fois le jumelage réussi, il suffit d'appuyer sur Suivant pour accéder à l'écran de commande de l'application.

Sortir du mode de jumelage

Appuyez sur la touche **MODE**  et maintenez-la enfoncée pendant 5 secondes jusqu'à ce que le voyant se mette à clignoter.

REMARQUE: Si votre appareil mobile ne se connecte pas à la machine à cuisiner dans un délai de 2 minutes, le mode de jumelage Bluetooth s'interrompt



www.team-cuisine.com



Apple, le logo Apple et l'iPhone sont des marques déposées d'Apple Inc. enregistré aux États-Unis et dans d'autres pays et régions. App Store est une marque de service d'Apple Inc. Google Play et le logo Google Play sont des marques déposées de Google LLC. Toutes les autres marques sont la propriété de leurs propriétaires respectifs.